

Edgeless Disk Light Installation Guide


IMPORTANT SAFETY INFORMATION

- 1. WARNING : RISK OF SHOCK** House electric current can cause painful shock or serious injury unless handled properly. For your safety, always remember to :
 - A : Turn off the power supply at the fuse or circuit breaker box before you install the fixture.
 - B : Ground the fixture to avoid potential electric shocks and to ensure reliable starting.
 - C : Double-check all connections to be sure they are tight and correct.
 - D : Wear rubber soled shoes and work on a sturdy wooden ladder.
- 2.** This fixture is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electrical codes. If you are unsure about your wiring, consult a qualified electrician or local electrical inspector, and check your local electrical code.
- 3. WARNING : RISK OF CUTS** Some metal parts in the fixture may have sharp edges. To prevent cuts and scrapes, wear gloves when handling the parts.
- 4.** Account for small parts and destroy packing material, as these may be hazardous to children.


PRODUCT SPECIFICATION

Size	Wattage (W)	Voltage (V)	Rated Input Frequency (Hz)	Dimension (DxH)
5inch	8W	120Vac	60HZ	φ137.5*H23.5mm
7inch	12W			φ179*H23.5mm
9inch	18W			φ224.2*H23.5mm
12inch	24W			φ299.2*H23.5mm
14inch	28W			φ350.8*H23.5mm


INSTALLATION




Step1: Turn off the power supply. Install the mounting bracket on the ceiling junction box using two screws provided as shown in Fig.1



Step2: Install the safety rope: secure one end to the bracket and the other end to the back cover of the luminaire.




Step3: Bring the luminaire near the junction box and make wiring electrical connections by using the wire nut. - Connect the ground green lead to the ground wire of the mounting bracket. Connect the black supply lead to the line fixture lead (black). Connect the white lead to the common fixture lead (white). Push connected wires into the junction box with caution.




Step4: Push the luminaire upward to fit the luminaire back side grooves with the ceiling mounted bracket. The installation is complete.

Edgeless Disk Light Installation Guide


UNINSTALLATION




Step1: There's "push" mark on both sides of the luminaire. Push the mark on one side horizontally in direction as shown in Fig.1, then the other side of the luminaire will detach from the bracket.



Step2: Push in the opposite direction as shown in Fig.2 to detach the other side of luminaire from the bracket.



Step3: Loosen the connection of the electrical wires



Step4: Unlock the safety rope to remove the luminaire

1. **WARNING** : Risk of fire. Use 120Vac, 60Hz circuits.
2. Suitable for damp locations. Before installing your lighting fixture, thoroughly review enclosed installation manual. If you do not have sufficient electrical wiring experience, please refer to a do-it-yourself wiring handbook or have your fixture installed by a qualified licensed electrician. All electrical connections must be in accordance with local and National Electrical Code(NEC) standards. Reliable operating temperature is -20 to +40 degrees Celsius(-4 to +104 degrees Fahrenheit).
3. pls obey fire prevention regulations, do not cover the fixture with any heat insulated materials.
4. Do not change the LED light source or driver inside under any circumstance.

Warranty:
5 years warranty



This product
is for indoor
use only



For use
with
dimmers